

Interface	Serial Number	Name	Description
PCS_CAN	1	485B	485B
	2	485A	485A
	3	ISO-G	Communication isolation
	4	CAN1H	CAN1 high
	5	CAN1L	CAN1 low
	6	ISO-G	Communication isolation
	7	232-TXD	232 transmit
	8	232-RXD	232 reception